






DEEP GLOW

Lighting the World's Waters

BULB REPLACEMENT INSTRUCTIONS

1. Unplug from power. Pull in light by cord and clean.
2. Make sure light is dry inside.
3. Remove wing-nuts, black flange, lens, old bulb and o-ring.
4. Clean and dry o-ring groove.
5. Install new o-ring into groove. Do not use any sealants or greases.
6. Install new bulb. **Handle bulb with a cloth.** Push pins back with small screw driver if necessary. Wiggle bulb back and forth to make sure bulb is seated correctly.
7. Replace lens and black flange.
8. Tighten wing nuts ¼ turn past hand-tight using pliers.
9. Back in the water and plug back in.

ENJOY!



www.DeepGlow.com

Phone: 727.234.1334
Fax: 727.234.1335
Toll Free: 888.871.3334

Office Mailing Address:
PO Box 55055
St Petersburg, FL 33732

Warehouse Shipping Address:
13131 56th Court, Suite 303
Clearwater, FL 33760